



## Spare Parts for BT35B

Item#	Illus. #	Description
101690	56	LATCH
S32024	57	SPRING, COMPRESSION
101691	58	BRACKET, FRAME/LATCH
S32066	59	PIN, SPECIAL
103425	60	ASSEMBLY, LATCH BRACKET
S32176	61	PIN, SPECIAL
101738	62	ROD, MAGAZINE
102813	63	RING, CYLINDER SLEEVE
101695	65	BUSHING, PUSHER
101730	66	PUSHER
101688	67	SPRING, COMPRESSION
100817	68	O-RING, 1.299X.103
102446	69	CORE, MAGAZINE
TVA5	70	KIT, S32/BT TRIGGER VLV
851554	71	O-RING, .703X.103
86459	72	O-RING, .614X.070
N50082A	73	ASSEMBLY, TRIGGER
SEQ2	74	KIT, SEQ TRIP CONV.
100387	75	SPRING, COMPRESSION
102388	76	SCREW, SFHCS M4X0.07X20
103380	78	ASSEMBLY, CORE PLATE
UB2104.6	79	PIN, SPRING .094 X .25
105235	80	SCREW, SOC. HD. CAP. M4 X 25