



FOR CONTACT TRIP MODELS



FOR TRIGGER OPERATED MODELS



**MIICFB**  
**PNEUMATIC TOOLS**  
**HERRAMIENTAS NEUMÁTICAS**  
**CLOUEURS PNEUMATIQUES**

## Spare Parts for MIICFB

Item#	Illus. #	Description
UA3810.4	1	SCREW,10-24 X 5/8 SHCS
BC1457	2	CAP
BC1329	3	GASKET
UA2810	4	SCREW,SHCS,8-32X5/8
LW8.2	5	WASHER, LOCK
BC846	6	WASHER,PLATE,POPPET
BC702	7	POPPET PISTON
86460	8	O-RING,1.859X.139
BC701	9	GASKET,POPPET PISTON
BC1328A	10	BODY
86314	11	O-RING,.864X.070
BC1331	12	VALVE SEAT
87251	13	O-RING,.739X.070
BC829	14	EXHAUST DEFLECTOR
SW8	15	WASHER, SHAKE PROOF
UA2804.3	16	SCREW,SLBIHS,8-32X1/4
88999	17	O-RING,.362X.103
BC1456A	18	PILOTED VALVE
88998	19	O-RING,.674X.103
BC1334	20	VALVE SPRING
106912	21	ASSEMBLY,PILOTING VALVE
T34002	22	SEAL
BC1339	23	TRIGGER
BC1336	24	TRIGGER PIVOT PIN
86468	25	RING, RETAINING
BC703	26	PLUNGER
86458	27	O-RING,.489X.070
850144	28	O-RING,.614X.070
121800	29	POPPET

850143	30	O-RING,.487x.103
BC711F	31	BUMPER
BC1175	32	DRIVER PISTON
850626	33	O-RING,1.984X.139
BC1455	34	PISTON STEM
UB4112.3	35	PIN, DOWEL .250 X .75
BC347	36	NYLON INSERT
102696	37	DRIVER
BC1103B	38	NOSE
102693	39	PLATE,WEAR
102692	40	GUIDE,BLADE
102697	41	ASSEMBLY,PUSHER
BC1318	42	SPRING,EXTENSION
102694	43	MAGAZINE
UB1106.1	44	PIN, SPRING .062 X .38
BC1317	45	SPRING,COVER STOP
BC1306	46	COVER STOP
102700	47	ASSEMBLY,MAGAZINE COVER
UA3816.4	49	SCREW,SHCS,10-24X1
UA4814.1	50	SCREW,1/4-20 X 7/8 SHCS
102702	51	PLATE,MAGAZINE
UA1804.8	52	SCREW,SFHCS,6-32X1/4
BC1341	53	ROCKER
BC1338	54	ROCKER PIVOT PIN.
BC1342	55	GUIDE
UA3808.15	56	SCREW,SHCS,8-36X1/2
BC1156	57	NOSE BRACKET SPRING
BC1343	58	FOOT,CONTACT
BC1347	59	VALVE EXTENSION
BC1008	60	SHIELD,NOSE
851364	61	LABEL, WARNING

BC1332	62	SEAL, VALVE
850916	63	WARNING LABEL
102950	64	LABEL,MODEL MIICFB
121799	65	O-RING 1.287 X .210