

| Item# | Illus. # | Description |
|-------------|-----------|-------------------------|
| P2145203262 | <u>1</u> | CAP |
| P2140001400 | <u>2</u> | BUMPER,PISTON STOP |
| S06A002700 | <u>3</u> | O-RING |
| P2145201062 | <u>4</u> | CLIP |
| G4208000 | <u>5</u> | FRAME UNIT |
| G0306900 | <u>6</u> | DRIVER UNIT |
| S06P001802 | <u>7</u> | O-RING |
| S06A012100 | <u>8</u> | O-RING |
| S06A002200 | <u>9</u> | O-RING |
| P2140001200 | <u>10</u> | BUMPER |
| P2140000163 | <u>11</u> | SLEEVE, CYLINDER |
| P2146301165 | <u>12</u> | PLATE,DRIVER GUIDE |
| P2146301865 | <u>13</u> | NOSE |
| P2145204362 | <u>14</u> | PLATE,NOSE |
| S0110414100 | <u>15</u> | HEX.SOC.HD.BOLT |
| P2190000563 | <u>16</u> | MAGAZINE |
| S0310414100 | <u>17</u> | FLAT HD.SOC.SCREW |
| P2196300965 | <u>18</u> | STOP PLATE |
| S0110408100 | <u>19</u> | HEX.SOC.HD.BOLT |
| P2195201162 | <u>20</u> | SPRING, PUSHER |
| P2146102557 | <u>21</u> | PUSHER |
| P2145202962 | <u>22</u> | ROLLER |
| P2145202862 | <u>23</u> | PIN,ROLLER |
| G2606300 | <u>24</u> | ASSY,CORE MAG UNIT,71LM |
| P2140003400 | <u>30</u> | GASKET,END CAP |
| P2140001340 | <u>31</u> | CAP,END |
| P2140002066 | <u>32</u> | LATCH,INSIDE |
| P2145203062 | <u>33</u> | SPRING,TORSION |
| P2190001266 | <u>34</u> | LATCH UNIT |
| P2140004666 | <u>35</u> | SPRING BUSHER |
| S3203022000 | <u>36</u> | SPIRAL PIN |
| P2140000666 | <u>37</u> | VALVE,ENERGY CONTROL |
| S06S000600 | <u>38</u> | O-RING |
| S2904018000 | <u>39</u> | SPIRAL PIN |
| S2904030000 | <u>40</u> | SPIRAL PIN |
| G1201800 | <u>41</u> | TRIGGER UNIT |
| S06A001600 | <u>42</u> | O-RING |
| P2142003100 | <u>43</u> | HEAD VALVE |
| S06Z003500 | <u>44</u> | O-RING |
| S06Z003600 | <u>45</u> | O-RING |
| P2145201562 | <u>46</u> | SPRNG,HEAD VALVE |
| P2140000300 | <u>47</u> | SEAL,EXHAUST |
| P2140004200 | <u>48</u> | SEAL WASHER |
| P2180000204 | <u>49</u> | HOUSING,TRIGGER VALVE |
| S06A012400 | <u>50</u> | O-RING |
| S06A012500 | <u>51</u> | O-RING |
| P2180000400 | <u>53</u> | SPRING,AUTOMATIC STEM |
| P2140001600 | <u>54</u> | SPRING |
| P2182000500 | <u>55</u> | STEM,AUTOMATIC |
| P2142003300 | <u>56</u> | STEM |
| S06A000200 | <u>57</u> | O-RING |

| | | |
|-------------|-----------|------------------------|
| P2182000800 | <u>58</u> | SHUTTLE |
| P2140000766 | <u>61</u> | SEAL, VALVE |
| P2180000104 | <u>62</u> | HOUSING, TRIGGER |
| S06S000400 | <u>63</u> | O-RING, 3.5MMX1.5MM |
| P2182000700 | <u>64</u> | HOUSING, NEEDLE |
| S06Z003900 | <u>65</u> | O-RING |
| P2182000600 | <u>66</u> | NEEDLE VALVE |
| S0801510000 | <u>67</u> | SPRING PIN |
| S1310316100 | <u>68</u> | BUTTON CROSS HD SCREW |
| P2180001066 | <u>69</u> | HOUSING, ADJUSTMENT |
| S0803028000 | <u>70</u> | SPRING PIN |
| P2185201162 | <u>71</u> | WHEEL, ADJUSTMENT |
| P2180001266 | <u>72</u> | RING, DETENT |
| P2185201462 | <u>73</u> | SPRING, ADJUSTMENT |
| P2185201362 | <u>74</u> | ROD, ADJUSTMENT |
| S0803014000 | <u>75</u> | SPRING PIN |
| P2180000366 | <u>76</u> | TRIGGER |
| P2185201662 | <u>77</u> | SPRING, TRIGGER |
| P2185201562 | <u>78</u> | PLATE, TRIGGER |
| B214002001 | <u>79</u> | WARNING LABEL (158577) |
| B214011001 | <u>80</u> | PRODUCT LABEL (158552) |
| P2140005800 | <u>81</u> | MUFFLER |
| P2146305665 | <u>82</u> | WRENCH (OPTIONAL) |
| P2140005700 | <u>83</u> | GAGE, SKIRT (OPTIONAL) |
| P2145205962 | <u>84</u> | HEAVY CAP |
| P2140006066 | <u>85</u> | BUMPER PLATE |
| P2140006262 | <u>86</u> | WIDE NOSE (OPTIONAL) |