


2 pages



**Duo-Fast**  
**Heavy Duty Finish Miller**  
**HFN-880D**  
 0055018  
 DUO-FAST CORPORATION  
 COUNTY DRIVE  
 HUNTLEY, ILLINOIS 60142-6700  
 U.S.A.

2000 DUO-FAST Corporation HFN-186-880D

**DISCONTINUED 2000**

**HFN-880D**

Always Wear Safety Glasses When Using Power Tools  
 XA-1011 CLEAR  
 XA-1022 TINTED

DENOTES CHANGE

TOOLS MUST BE REPAIRED ONLY WITH FACTORY AUTHORIZED PARTS  
 SIEMPRE REPARA LAS HERRAMIENTAS SOLO CON PARTES DE REPUESTO AUTORIZADAS POR DUO-FAST

DISCONTINUED 2000

**HFN-880D**

UNIQUE #	PART NO.	DESCRIPTION	REPLACED BY	UNIQUE #	PART NO.	DESCRIPTION	REPLACED BY
0363760	2562	SCREW		0419564	MS-100-8	CAP GASKET	
0364792	3636	NUT		0452755	MS-101-12	SHEAR PROOF PIN	
0366375	8209	WASHER		0419648	MS-101-6	ROLL PIN	
0384750	3626A	SCREW		0419705	MS-103-8	SCREW	
0393835	AN-103-1	SCREW		0419903	MS-110-11	HEX BUSHING	
0393883	AN-103-2	SCREW		0437392	MS-110-16	SLEEVE	
0397976	CA-103-15	SCREW		1013122	MS-110-5N	BUMPER	MS-110-5P
0442681	CN-105-1	NUT		0419879	MS-110-9	BIAS RING	
0443465	CN-105-4	WASHER		0420874	MS-115-1	PISTON	
0446526	CNB-103-4	SCREW		0420281	MS-120-2	POPPET	
0317776	DS-120-6	EXHAUST DEFLECTOR		0420299	MS-120-3	EXHAUST SEAL	
0431931	HFN-102-1	SPRING		0420323	MS-120-6	DUMP VALVE COVER PLATE	
0432161	HFN-103-2	SCREW		0408066	MS-120-7	SPRING	
0432211	HFN-103-3	SCREW		0408096	MS-120-7	SPRING	
0455915	HFN-103-4	SCREW		0046466	MS-702-2	SPRING	
0433086	HFN-105-1	BUSHING		0165373	MS-702-6	SPRING	
0433516	HFN-105-2	BUSHING		0408278	MS-703-2	SCREW	
0433821	HFN-106-1	SPACER		0407965	MS-705	GANG NUT ASM.	
0451971	HFN-106-6	SPACER		0263632	MS-705-4	FLANGE NUT	
0454777	HFN-106-7	SPACER		0408302	MS-708-2	LOOKWASHER	
0044321	HFN-108-3	PRODUCT LABEL		0408310	MS-709-1	BUSHING	
0448977	HFN-115	PISTON ASSEMBLY		0277632	MS-709-6	VALVE HOUS. BUSHING	
0449371	HFN-115-2	DRIVER BLADE		0408385	MS-711-1	CYLINDER	
0448613	HFN-130-2	BASE END PLATE		0046474	MS-712-8	NOSE PLATE	
0450478	HFN-130-P1	MAG BASE PART. ASM.		0467035	MS-714-1B	VALVE CARTRIDGE	
0449058	HFN-131-P1	TRACK PART. ASM.		0408198	MS-719-1	TRIGGER VALVE	
0448959	HFN-135-1	PUSHER		0408450	MS-719-2	SPRING GUIDE, LOWER	
0448678	HFN-135-P1	MAG COVER PART. ASM.		0408492	MS-733-4	O-RING	
0451385	HFN-140-1B	REAR NOSE		0196352	OR-005-70L	O-RING	
0452052	HFN-140-2	SHEAR BLOCK		0197186	OR-008-70L	O-RING	
0446746	HFN-141-1B	FRONT NOSE		0197194	OR-010-70L	O-RING	
0505859	HFN-142-1	LATCH		0197202	OR-011-90N	O-RING	
0505974	HFN-203-1	SCREW		0390761	OR-011-90N	O-RING	
0505974	HFN-203-4	SAFETY YOKE - NO MAR		0414342	OR-014-70N	O-RING	
0505867	HFN-233-2	NO-MAR YOKE PAD		0408070	OR-017-70N	O-RING	
0505875	HFN-233-3	BUSHING		0198028	OR-029-70L	O-RING	
0320440	HFN-293-1	COVER PLATE		0419531	OR-030-90N	O-RING	
0413922	ISN-105-2	BRACKET, REAR SUPPORT		0402289	OR-031-70N	O-RING	
0418061	KN-130-12	NUT		0201756	OR-122-70L	O-RING	
0453071	LPN-103-3	PUSHER SPRING		0202358	OR-133-70L	O-RING	
0528018	MCM-110-4	SET SCREW		0412478	OR-138-90N	O-RING	
1011861	MCM-208-1	GRIP		0202374	OR-137-70L	O-RING	
1011871	MCM-210-P1	LABEL - HANDLE		0202382	OR-139-70L	O-RING	
0528778	MCM-312-1	HANDLE PART. ASM.		0192799	OR-142-70L	O-RING	
0168344	MM-101-3	VALVE HOUSING (MACH.)		0202408	OR-146-70L	O-RING	
0017343	MM-102-5	TRIGGER PIN		0391154	OR-227-70N	O-RING	
0022947	MM-102-6	SPRING		0412510	OR-328-90N	O-RING	
0168385	MM-102-7	SPRINGS		0427799	SP-182-37	SCREW	
0023051	MM-103-1	SCREW		0456772	XA-1011	SAFETY GLASSES, CLEAR	
0017335	MM-103-4	SCREW		0277606	XA-1022	SAFETY GLASSES, TINTED	
0169288	MM-112-2	TRIGGER RETAINER		0153397	XH-102-10	SPRING	
0048314	MM-120-5	RETURN VALVE		0483479	XH-108-18	WARNING LABEL	
0169284	MM-120-5	DUMP VALVE		0353847	XH-108-31	SEC. LABEL	
0169383	MM-196-2	SEAL RING		0024976	XH-108-45	MADE IN AMERICA LABEL	
0457812	MM-303-1	SCREW		0152058	XO-1151-1	LEVER	
0457820	MM-320	CAP ASSEMBLY		0212399	XO-1151-5	PUSH ROD	
0335356	MM-320-1	CAP		1012233	XO-2151-2	TRIGGER	

**DISCONTINUED 2000**

HFN-880D  
KVC (10) 04/00