



<u>UNIQUE #</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REPLACES</u>	<u>UNIQUE #</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REPLACES</u>
0383760	2562	SCREW		0451773	LFN-101-4	YOKE PIVOT PIN	
0384792	3636	NUT		0455063	LFN-102-1	SPRING (LATCH)	
0390252	AA-40	E-RING		0451856	LFN-103-2	SCREW	
0390450	AA-62	NUT		0455071	LFN-103-3	SET SCREW	
0397976	CA-103-15	SCREW		0451781	LFN-105-2	BUSHING, SHEAR BLOCK	
0446526	CNB-103-4	SCREW		0451716	LFN-106-2	SPACER	
0410720	GO-104-1	E-RING		0453712	LFN-106-6	SPACER	
0412098	HA-110	SCREW		0065904	LFN-110-4	CYLINDER SLEEVE ASM	
0433086	HFN-105-1	BUSHING		0455774	LFN-114-1	NOSE PLATE (MACH)	
0448746	HFN-142-1	LATCH		0453589	LFN-115-3	DRIVER BLADE	
0412627	IN-103-8	SCREW		0454165	LFN-130-13	WEAR PLATE	
0413047	IN-120-8	SPRING		0454447	LFN-131-P1	TRACK PARTIAL ASM.	
0413922	ISN-105-2	NUT		0453977	LFN-133-4	YOKE COVER PLATE	
0288381	KN-100-2L	O-RING		0453951	LFN-141	FRONT NOSE (MACH)	
0288332	KN-100-5L	O-RING		0345785	LFN-206-3	YOKE SPRING RETAINER	
0417154	KN-101-1	TRIGGER PIN		0067926	LFN-208-1A	MODEL LABEL	
0417162	KN-101-2	PIN		0053603	LFN-230-3	BASE END PLATE	
0417204	KN-103-2	SCREW		0178194	LFN-230-4	BASE STOP	
0417246	KN-103-9	SCREW		0178202	LFN-233	WORK CONTACT ELEMENT	
0417253	KN-103-10	SCREW		0187559	LFN-235-1	PUSHER	
0417345	KN-106-1	STEP WASHER		0174342	LFN-240-1	REAR NOSE (MACH)	
0417451	KN-110-7	UPPER YOKE		0052415	LFN-240-2	SHEAR BLOCK	
0417485	KN-110-9	YOKE SPRING		0456160	LFN-330-P1	MAG. BASE PARTIAL ASM.	
0417501	KN-110-13	SPRING POST		0372128	LFN-336-P1	MAG. COVER PARTIAL ASM.	
0417600	KN-112-4	SPRING		0419705	MS-103-8	SCREW	
0417634	KN-113-2	TRIGGER VALVE		0420331	MS-120-7	SPRING	
0417642	KN-113-3	SAFETY VALVE		0408286	MS-705-3	LATCH RETAINER	
0417709	KN-115-1	PISTON		0408302	MS-706-2	WASHER	
0417782	KN-120-3	CAP GASKET		0197186	OR-008-70L	O-RING	
0417824	KN-120-7	EXHAUST DEFLECTOR		0197194	OR-010-70L	O-RING	
0417832	KN-120-8	COVER PLATE		0442590	OR-026-80N	O-RING	
0417857	KN-120-10	DUMP VALVE COVER PLATE		0419531	OR-030-90N	O-RING	
0418061	KN-130-12	PUSHER SPRING		0198408	OR-102-70L	O-RING	
0418145	KN-133-2	YOKE CROSS LINK		0201731	OR-120-70L	O-RING	
0040022	KN-203-1	DOG POINT SET SCREW		0448860	OR-121-75V	O-RING	
0282905	KN-210-5	BUMPER		0417147	OR-123-70N	O-RING	
0098665	KN-213-4	VALVE HOUSING GASKET		0201830	OR-125-70L	O-RING	
0068973	KN-303-1	SCREW		0202291	OR-131-70L	O-RING	
0068221	KN-310-2	HANDLE REAR LEG		0443549	RS-104-2	E-RING	
0067066	KN-310-3	HANDLE GRIP		0456772	XA-1011	SAFETY GLASSES, CLEAR	
0072116	KN-310-6	NOSE PLATE GASKET		0277806	XA-1022	SAFETY GLASSES, TINTED	
0074328	KN-311	HANDLE PLUG		0456657	XH-103-7	SCREW	
1011865	KN-410-P1	HANDLE ASSEMBLY		0388009	XH-106-1	WASHER	
0442608	KW-120	CAP ASSEMBLY (REF)		0353847	XH-108-31	CYCLE LABEL	
0442616	KW-120-1	CAP (MACH)		0067942	XH-108-61	WARNING LABEL	
0442632	KW-120-2	POPPET		0194605	XO-1046-1	CYCLE VALVE	
0442640	KW-120-3	POPPET SEAL		0194613	XO-1046-2	PLUG VALVE	
0442665	KW-120-9	DUMP VALVE		1011868	XO-2096	VALVE HOUSING	
0374512	KW-220-5	EXHAUST SEAL		1011863	XO-2137	TRIGGER	

\* = NEW PART    > = PART CHANGE